



Products: Audio Analyzers

R&S®UPV, R&S®UPV66, R&S®UPP200, R&S®UPP400, R&S®UPP800

## Resolving Security Issues when working with R&S®UPV, R&S®UPV66, R&S®UPP200, R&S®UPP400, R&S®UPP800 in Secure Areas

Based upon the user's security requirements, this document describes the Rohde & Schwarz options available to address the user's audio analyzer needs. It also covers the different memory types and locations where user information can be stored in the Audio Analyzer R&S®UPV. In addition this document also covers the following R&S® Audio Analyzers:

R&S®UPV66, R&S®UPP200, R&S®UPP400, R&S®UPP800



**Overview .....3**

**Instrument Models Covered.....3**

**Battery Information .....3**

**Types of Memory in the R&S®UPV and its Security Concerns.....4**

**Information Storage in the R&S®UPV Audio Analyzer.....5**

**Maintaining Security / Sanitizing .....6**

**Performing Firmware Updates and Backing-up User Data in Sensitive Areas .....8**

**Special considerations for USB ports .....8**

**Special considerations for LAN ports .....9**

**Additional Information.....10**

## Overview

In many cases it is imperative that R&S®UPV, R&S®UPV66, R&S®UPP200, R&S®UPP400 or R&S®UPP800 audio analyzers can be used in a secured environment. Generally these highly secured environments will not allow any test equipment to leave the area unless it can be proven that no user information will leave with the test equipment. Security concerns can arise when audio analyzers need to leave a secured area to be calibrated or serviced.

In the following the types of memory and their usage in the R&S®UPV, R&S®UPV66, R&S®UPP200, R&S®UPP400 or R&S®UPP800 audio analyzers is described. It also addresses methods of ensuring that no user data will leave the secured area if the product has to be removed for calibration or service needs.

## Instrument Models Covered

### R&S® Audio Analyzer



- R&S®UPV
- R&S®UPV66
- R&S®UPP200
- R&S®UPP400
- R&S®UPP800

In the following document, as instrument it is always referred to the R&S®UPV while the information is valid for all models covered. If there are some special points for one specific instrument, it is given and stated clearly.

## Battery Information

The only battery used on the R&S®UPV is located on the CPU board. This battery is used exclusively for powering the real-time clock in the chipset and the CMOS-SRAM memory. The CMOS-SRAM memory is used only to store the BIOS setup.

**The CMOS-SRAM is not a security concern.**

## Types of Memory in the R&S®UPV and its Security Concerns

### SDRAM Memory

The R&S®UPV has 512/1024 Mbytes of SDRAM memory on the CPU board. SDRAMs are volatile memories and lose their data when the power supply is switched off. The SDRAM will be unreadable within one minute after the power is removed from the instrument.

**The SDRAM is not a security concern.**

### EEPROM Memory

Every module, with the exception of the R&S®UPV-B1 and R&S®UPV-B3 options, is equipped with a serial EEPROM. These EEPROMs have a capacity of 2 Kbyte (memory size might be subject to changes without further notice) and contain module-relevant data such as the serial number of the module, calibration data, etc, and cannot be accessed by the user. The data can only be changed by the service center when the R&S®UPV or the module is calibrated. User data cannot be stored on the EEPROM memory.

**The EEPROM is not a security concern.**

### FLASH Memory

There is one FLASH memory in the R&S®UPV. This 512k FLASH memory contains the BIOS. It is on the CPU board of the R&S®UPV.

In the R&S®UPP models, a second 1 Mbyte flash memory contains module-relevant data such as the serial number of the module, options, etc. It is located on the motherboard of the R&S®UPP.

The user cannot access either memory. The FLASH memory data can only be changed by the service center.

**The FLASH memory is not a security concern.**

### Hard Drive

The hard drive is the nonvolatile storage medium in the R&S®UPV.

Because the hard drive is nonvolatile, user data is not erased when power is removed from the instrument.

The following information is stored on hard drive:

- The R&S®UPV's operating system (Microsoft Windows®)
- The R&S®UPV's firmware including optional software for SW-options
- Instruments states, setups and user data (e.g. waveforms)

**The hard drive is a security concern.**

## Information Storage in the R&S®UPV Audio Analyzer

DATA	SDRAM	FLASH	EEPROM	HARD DRIVE
Temporary Information storage for the CPU (CPU, Cache and Swap Area)	N			N
BIOS		N		
<b>R&amp;S®UPP only:</b> Hardware Info, Serial Number, Product Options		N		
<b>R&amp;S®UPV only:</b> Hardware Info, Serial Number, Product Options			N	
Calibration Correction Constants			N	
Operating System and Instrument Firmware				N
Instruments states, setups and user data (e.g. waveforms)				S

**N = No security concern**

**S = Security concern**

## Maintaining Security / Sanitizing

Clearing the different types of memory

### SDRAM

This memory is volatile. All you have to do is remove the power from the instrument and all data stored in it will be lost.

### Hard Drive

All user specific data like

- Instrument states and setups
- Waveforms, data lists, traces, ...

is stored on the internal hard drive. Simply deleting these files is not sufficient from a security perspective.

**To meet security requirements, the R&S®UPV provides a sanitizing procedure that ensures that user data will be irretrievably extinguished without removing storage from the instrument.**

All necessary parts and tools are available from the R&S service department:

- Recovery CD with sanitizing program, Order No. 1411.2051.00, will be available with R&S®UPV firmware 3.0.0 or higher
- External CD drive (R&S®UPV66, R&S®UPP200, R&S®UPP400 and R&S®UPP800)
- Spare hard disks (in case of the hard disk must be destroyed physically)

## Sanitizing

To sanitize an R&S®UPV, perform the following steps:

1. Connect the external CD drive to the instrument (R&S®UPV66, R&S®UPP200, R&S®UPP400 and R&S®UPP800)
2. Insert the Recovery CD
3. Boot the instrument
4. Select “wipe disk” from the menu

After sanitization the instrument is not operational. The following two steps must be performed in order to repair it:

1. Recover the operating system by using the Recovery CD
2. Install the firmware from USB. The newest version (recommended) can be downloaded from [www.rohde-schwarz.com](http://www.rohde-schwarz.com), older versions can be retrieved from the R&S service department.

This sanitization meets the following requirements:

1. **It is according to DOD 5220.22-M [NISPOM 8-306].**
2. User data, passwords and other confidential data will be irretrievably destroyed.
3. This also applies to data fragments stored in deleted files or in memory blocks marked as defective during instrument operation.
4. Passwords are reset to factory values, USB and LAN interfaces are enabled.

In the case hard disks must be destroyed physically, empty hard disks are also available from the R&S service department. The replacement is explained in detail in the service manual delivered with R&S®UPV on a CD-ROM.

## Performing Firmware Updates and Backing-up User Data in Sensitive Areas

Rohde & Schwarz highly recommends, but does not require, the users of its products, to maintain their products with the latest updates and to regularly back-up important user data that can be erased. Firmware updates are available from the R&S website. How does a user perform firmware updates and back-up user data in sensitive areas? There are several options available for the user to safely perform these operations without compromising the security of the sensitive areas.

### Via the USB port

R&S®UPV audio analyzers are equipped with USB ports as standard equipment. As described below, users can disable these ports. For users that have not elected to disable the USB ports a memory stick can be used to transport a firmware update into a secure area. The files of an instrument firmware update should be copied from the USB stick to the internal hard drive. From the hard drive the update can be performed. The USB stick can likewise hold or transport user data back-ups to an approved storage medium.

### Via LAN

R&S®UPV audio analyzers are equipped with LAN as standard equipment. As described below, users can disable these ports. For users that have not elected to disable the LAN the LAN interface can be used to transport the firmware update onto the instrument. There the firmware update can be stored on the internal hard drive. From the hard drive the update can be performed.

## Special considerations for USB ports

USB ports can pose a security threat in high-security locations. Generally, this threat comes from small USB pen drives (a.k.a. memory sticks, key drives, etc) which can be very easily concealed, yet can quickly read/write several GBytes of data.

### To disable USB Ports

The R&S®UPV audio analyzer can disable its USB port by means of BIOS if the factory date is March 2007 or later. Setting a BIOS password is recommended.

All R&S®UPV66, R&S®UPP200, R&S®UPP400 and R&S®UPP800 audio analyzers can disable their USB ports by means of BIOS. Setting a BIOS password is recommended.

## Special considerations for LAN ports

Some users select not to install a LAN within their high-security locations.

### **To disable LAN Ports**

The R&S®UPV audio analyzer can disable its LAN ports by means of BIOS. Setting a BIOS password is recommended.

## Additional Information

Please contact your Rohde & Schwarz support centre for comments and further suggestions, or find the current address on the homepage <http://www.customersupport.rohde-schwarz.com>.

Regional contact:

**Europe, Africa, Middle East**

+49 1805 12 42 42\* or

+49 89 4129 137 74

[customersupport@rohde-schwarz.com](mailto:customersupport@rohde-schwarz.com)

**North America**

1-888-TEST-RSA (1-888-837-8772)

[customer.support@rsa.rohde-schwarz.com](mailto:customer.support@rsa.rohde-schwarz.com)

**Latin America**

+1-410-910-7988

[customersupport.la@rohde-schwarz.com](mailto:customersupport.la@rohde-schwarz.com)

**Asia/Pacific**

+65 65 13 04 88

[customersupport.asia@rohde-schwarz.com](mailto:customersupport.asia@rohde-schwarz.com)



ROHDE & SCHWARZ GmbH & Co. KG · Mühldorfstraße 15 · D-81671 München · P.O.B 80 14 69 · D-81614 München · Telephone  
+49 89 4129 -0 · Fax +49 89 4129 - 13777 · Internet: <http://www.rohde-schwarz.com>